

Specification Sheet BoneDry[™] WP

2034-C Van Buren Ave. • Indian Trail, NC 28079 • Phone: 704.334.8222

BoneDry™ WP Waterproofing Membrane is a modified asphalt emulsion developed for use as a high quality below grade waterproofing barrier. **BoneDry™ WP**'s low vapor permeance, outstanding adhesion, and superior combination of hardness and flexibility make it your best choice for any below grade waterproofing application. Some typical applications include waterproofing residential basements and crawl spaces; **BoneDry™ WP** also plays a key role in all the BD series waterproofing systems.

BoneDry™ WP is spray applied and can instantly build virtually any thickness¹ your job demands. Instant thickness means you can install the remainder of your waterproofing system immediately after the product has been sprayed – no additional trips to complete waterproofing because your membrane isn't cure.

Property	Test Method	Value	For more application
Color Non Volatile Solids Density Coverage Rate Thickness Elongation Tensile Strength Adhesion to Concrete Water Degradation Water Vapor Permeance Mold Growth & Bacterial Attack Low Temp Flexibility Crack Bridging Hardness	ASTM D-412 ASTM D-412 ASTM C-836 ASTM D-2939 ASTM E-96 Wet ASTM D-3273, 3274 ASTM C-836 ASTM C-836 ASTM C-836	Black/Brown 63% ± 2% 8.3 lbs/gal. 22-25 sq. ft./gal. 40 mil (Dry) > 1000% 38 psi Exceeds No Degradation 0.0267 gr/hr*sq.ft. No Degradation No Cracking No Loss of Adhesion 75	information visit www.drydogbarriers.com or email us info@drydogbarriers.com
Hardness	ASTM C-836	/5	

Applications

- Masonry Foundations
- Poured Foundations
- Pre-Cast Foundations
- Horizontal Waterproofing
- Transition Detailing
- Planters
- Retaining Walls
- Cavity Wall air barrier
- Seamless Flashing

¹ To obtain recommended thickness this product must be used with BoneDry[™] Accelerator.



BoneDry™ WP waterproofing membrane shown with available12″ DrainMax™ foundation strip drain to make the BD1000 Waterproofing System

The information and recommendations discussed in this publication are believed to be correct. However, this should not be accepted as a guarantee of their accuracy, and confirming test should be run in your own plant or laboratory. No statement should be construed as a recommendation for any use, which would violate any patent rights. Nothing contained herein shall constitute a warranty with respect to the products described or their use. BoneDry™WP Issue: A Revision: 2 Date: 02/15/07